

COPPER PIPES

1. Draw plumb line from centre of gutter outlet to floor.
2. Drill single hole using masonry drill at maximum 2.0m centres or where appropriate. Use appropriate rawlplug.
3. Screw coach screw in to wall. Pliers may be used.
4. Screw saddle bracket in to position and leave open.
5. Place pipe in position, close saddle bracket and tighten thumb screw.
6. Bends can be used to make offsets and can be extended using a section of pipe between them.
7. Shoes are available and should be secured using saddle bracket as before.

